



## Legend

		_						
	Airbag	å	Stored gas inflator		Seat belt pretensioner	SRS control unit		Pedestrian protection active system
	Automatic rollover protection system		Gas strut / Preloaded spring		High strength zone	Zone requiring special attention		
000 000	Battery low voltage	#	Ultra-capacitor, low voltage		Fuel tank	Gas tank		Safety valve
0 0	Battery pack, high voltage	N	High voltage power cable / component	//	High voltage device that disconnects High voltage	Fuse box disabling high voltage	H/1	High voltage ultra-capacitor,
	Fuel tank content Gasoline / Ethanol							